

Funjump Rigging

Assembling your new GoPro HD Handcam glove

Step 1: Gather the three necessary components



Step 2: Remove the video camera from its housing



Step 3: Remove front bezel, lens protector, and rubber ring from HD Hero housing



Step 4: Reinsert one screw into the housing for storage, because we'll be using only five



Step 6: Place the white plastic ring around the camera lens, with blue dot at top



Step 7: Insert camera fully into glove and center the white ring around the lens



Step 8: Place the lens cover and rubber ring over the lens



Step 9: Place the black bezel over lens protector and line up holes with white ring holes



Step 10: Insert one screw upper left... only far enough to catch and hold now



Step 11: Insert second screw bottom right... only tighten enough to catch threads



Step 12: Insert the rest of the screws, and once all are inserted snug them all down



Step 13: Close the snap to secure the camera inside the glove



Note: Whenever you remove the camera, simply pull out on the front like this



Note: You can insert and remove memory cards while camera remains in glove



Note: To charge the camera battery, simply unsnap and plug in USB cable



Please send any questions or comments to Chris Warnock at Funjump rigging:
wxyz@mindspring.com